

# Valore Wireless Numeric Keypad (AC128)

# VALORE

Thank you for purchasing the Valore Wireless Numeric Keypad (AC128).

- 28-key wireless numeric keypad makes working on spreadsheets and accounting applications a breeze
- Accurate and precise with every touch
- Aluminium alloy cover
- Built-in rechargeable battery

**Important:** Please read the user manual thoroughly before using your Wireless Numeric Keyboard.


## Specifications:

- Transmission: Up to 10m
- Battery type: Built-in 140mAh lithium battery
- System supports: Windows XP and above  
macOS 10 X and above  
Android
- Material: Aluminium alloy + PC
- Dimensions (L x W x D): 121 x 100 x 12.5mm
- Weight: 93g

## Package Contents:

- Wireless numeric keypad
- USB cable (600mm)

## UNDERSTANDING THE PRODUCT



# START USING WIRELESS NUMERIC KEYPAD

## 1) Pairing

- a) Turn on power switch, wireless indicator will blink once
- b) Press pairing button for 1-2 seconds, wireless indicator will start to flash
- c) Turn on computer's Bluetooth settings
- d) Search and connect "Valore AC128" from Bluetooth settings
- e) Wireless numeric keypad is ready for use when "Connection successful" is prompted

## 3) Charging

When power indicator turn red and flashes, battery is low.

Use the charging cable provided to charge the keypad. When charging, LED indicator will be red. When charging is complete, red indicator will go off.



## TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at [v.info@valore.sg](mailto:v.info@valore.sg).
- For Warranty Registration, visit [www.valore.sg](http://www.valore.sg).

### Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the product in a high temperature environment.
- Do not place the product near a fire or other excessively hot environments.
- Do not expose the product to moisture or submerge it in liquid. Keep product dry at all times.
- Do not attempt to charge the product using any other method or connection other than the product's provided charging cable.
- Do not disassemble this product or attempt to repair or modify it in any manner.
- Battery usage by children should be supervised
- Be cautious of excessive drops, bumps, abrasions or other impacts to this product. If there is any damage to the product such as dents, punctures, tears, deformities or corrosion, stop using the product and contact us immediately via email at [v.info@valore.sg](mailto:v.info@valore.sg), or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at [v.info@valore.sg](mailto:v.info@valore.sg).

### DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes. The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with  
IMDA Standards  
DA102803



Inspired by Valore Singapore

For full range of Valore products visit [www.valore.sg](http://www.valore.sg)