

Rechargeable Electric Air Duster (AC141)

VALORE

Thank you for purchasing Valore Rechargeable Electric Air Duster (AC141).

- Ergonomic design with simple operation
- No chemical residue
- Portable & powerful
- Eco-friendly
- USB-C charging

Important: Please read the user manual thoroughly before using your electric air duster.


Specifications:

- Battery type: Built-in Li-ion battery 6000mAh
- Power supply: DC5V
- Rated power: 60W
- Charging time: Approximately 4 hours
- Working time: Up to 30 mins (at lowest speed)
- Noise level: <80dB
- Material: ABS
- Dimensions (L x W x D): 189 x 79 x 131mm
- Weight: 385g

Package Contents:

- Rechargeable electric air duster
- USB-A to USB-C charging cable

UNDERSTANDING THE PRODUCT




START USING THE RECHARGEABLE ELECTRIC AIR DUSTER

How To Charge

1. Insert USB cable into the air duster charging port. The indicator light flickers red while it is charging. It will be solid red when fully charged.
2. Connect the cable with a 5V/2A USB outlet, such as USB charger, cell phone adaptor, laptop or power bank. However a 5V/2A adaptor would work best to greatly shorten the charging time.

How To Use

1. Release the nozzle from the nozzle hole and put it to the air outlet.
2. Long press the on/off button for 3 seconds to run the unit, press switch button again to adjust one gear position (low, high, shutdown) cycle. Indicator light will always be on.
3. Press the LED on/off button to control the LED light.



TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the product in a high temperature environment.
- Do not place the product near a fire or other excessively hot environments.
- Do not expose this product to moisture or submerge it in liquid. Keep product dry at all times.
- Do not attempt to charge the product using any other method or connection other than the product's provided charging cable.
- Do not disassemble this product or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this product. If there is any damage to the product such as dents, punctures, tears, deformities or corrosion, stop using the product and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Challenger Technologies Limited. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg