

2-Way Connectivity Wireless Mouse (AC90)

VALORE

Thank you for purchasing the Valore 2-Way Connectivity Wireless Mouse (AC90).

- Connect up to 2 computers

Important: Please read the user manual thoroughly before using your wireless mouse.



Specifications:

- Transmission: Up to 10m
- Connectivity: Wireless & 2.4GHz USB receiver
- Resolution: 800/1000/1200/1600DPI
- Supports: Windows XP and above
: macOS 10 X and above
- Battery type: AA x 1 (not included)

Package Contents:

- 2-way connectivity wireless mouse
- USB receiver

UNDERSTANDING THE PRODUCT



START USING WIRELESS MOUSE

1) ON/OFF

Move switch to on or off wireless mouse.

2) Function switch

Charging between Bluetooth and 2.4GHz wireless mode.

3) LED indicator

Blue & Red LED work as follow:

- a) When pressing DPI button, the indicator will light up to 4 times to show the difference of DPI speed. (Blue when under 2.4GHz wireless mode, Red when under Bluetooth mode).
- b) When pressing Function switch. 2.4GHz wireless mode the indicator shows Blue for 3 secs and turns off. Switching to Bluetooth mode, the indicator shows Red for 3 secs and turns off.

4) DPI button (1-4 levels)

800 dpi (1st level) / 1200 dpi (2nd level: default) / 1600 dpi (3rd level) / 2400 dpi (4th level)

5) Pairing

- a) Under 2.4GHz wireless mode, no pairing is needed.
Plug USB receiver into the computer and make sure the indicator light is under 2.4GHz wireless mode (Blue LED).
- b) Bluetooth pairing: When in 2.4GHz wireless mode, short press once on the Function switch, the indicator light will turn to Red. Wait for 2-3 secs, the Red LED will blink and now is under pairing mode. Search for "Valore AC90" from your computer's Bluetooth list.
Once Bluetooth is paired successfully, computer will memorise the device and auto connect in the future.

TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the product in a high temperature environment.
- Do not place the product near a fire or other excessively hot environments.
- Do not expose the product to moisture or submerge it in liquid. Keep product dry at all times.
- Do not attempt to charge the product using any other method or connection other than the product's provided charging cable.
- Do not disassemble this product or attempt to repair or modify it in any manner.
- Battery usage by children should be supervised
- Be cautious of excessive drops, bumps, abrasions or other impacts to this product. If there is any damage to the product such as dents, punctures, tears, deformities or corrosion, stop using the product and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes. The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with
IMDA Standards
DA102803

Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg