

Ultra-Slim Wireless Keyboard (BTK01)

VALORE

Thank you for purchasing the Valore Ultra-Slim Wireless Keyboard (BTK01).

Travelers or users on the go will like this wireless keyboard's ultra slim profile and compact, lightweight design. Type with precision while saving yourself some space on your desktop or bag.

Important: Please read the user manual thoroughly before using your Selfie Stick.

Specifications:

- Wireless distance: Up to 10m
- Battery type: Lithium battery/280mAh
- Modulation system: GFSK
- Operation voltage: 3.0 – 4.2V
- Standby time: 30 days
- Sleep current: < 40ua
- Charging time: 2 hours
- Key force: 80 ± 10g
- Key life span: 5 million hits
- Material: ABS
- Dimension (L x W x H): 240 x 130 x 6.5mm
- Weight: 176g

Package Contents:

- Wireless keyboard
- USB charging cable

UNDERSTANDING THE PRODUCT



- ① Bluetooth connect button
- ② On/Off switch
- ③ Micro USB charging port
- ④ Indicators


START USING WIRELESS KEYBOARD

1) How to connect

Switch on Bluetooth function on your device.

Switch on the wireless keyboard by sliding the On/Off switch to On.

Press the Bluetooth connection button on the wireless keyboard.



Select 'Valore BTK01' on your device's Bluetooth list.

Input pairing code displayed on your device and press 'Enter' on the wireless keyboard.

2) Charging your wireless keyboard

Plug in the Micro USB cable provided to the charging port located on the right side of the wireless keyboard.











Charging light(red):turns on when charging,turns off when fully charge.

3) Keyboard functions
























Android systems

	Home		Back		Search
	Map		Mute		Volume down
	Volume up		Previous track		play/pause
	Next track		Lock		Web browser
	Email	FN+	switch Language	Ctrl+ Shift	Language switching
Ctrl+C	Copy	Ctrl+V	paste	Ctrl+X	cut
Ctrl+A	select All	FN+	Virtual keyboard	FN+ Pgup	Move the cursor to the top
FN+ Home	Move the cursor to the beginning	FN+ PgDn	Move the cursor to the bottom	FN+ End	Move the cursor to the end

Windows systems

	Web browser		Email		Language switching
FN+ 	switch Language	Ctrl+ Shift	Language switching	Ctrl+A	select All
	select All	Ctrl+C	Copy		Copy
Ctrl+V	paste		paste	Ctrl+X	cut
	cut	FN+ Home	Move the cursor to the beginning	FN+ End	Move the cursor to the end

IOS systems

	Home		Slideshow		Mute
	Volume down		Volume up		Previous track
	play/pause		Next track		Lock
	Search		Virtual keyboard	FN+ 	Virtual keyboard
FN+ Pgup	Move the cursor to the top	FN+ Home	Move the cursor to the beginning	FN+ PgDn	Move the cursor to the bottom
FN+ End	Move the cursor to the end		Language switching	FN+ 	switch Language
	select All		select All		Copy
	Copy		paste		paste
	cut		cut		screen shot

For iOS 10.0 and above, to activate Caps Lock function, go to:
Settings > General > Keyboard > Hardware Keyboard > **Switch off** Caps Lock Latin Switch

TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the product in a high temperature environment.
- Do not place the product near a fire or other excessively hot environments.
- Do not expose the product to moisture or submerge it in liquid. Keep product dry at all times.
- Do not attempt to charge the product using any other method or connection other than the product's provided charging cable.
- Do not disassemble this product or attempt to repair or modify it in any manner.
- Battery usage by children should be supervised
- Be cautious of excessive drops, bumps, abrasions or other impacts to this product. If there is any damage to the product such as dents, punctures, tears, deformities or corrosion, stop using the product and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes. The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with
IMDA Standards
DA103331



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg