

# Valore Malurus – Wireless Speaker with Subwoofer (BTS05)

# VALORE

Thank you for purchasing the Valore Malurus – Wireless Speaker with Subwoofer (BTS05).

With the full stereo left and right speakers and a compact subwoofer for enhanced bass, the Valore Malurus is a must-have to take your audio journey to the next level and enjoy your favourite music, videos and streaming content never before.

**Important:** Please read the user manual thoroughly before using your wireless speaker.


## Specifications:

- Wireless range: Up to 5m
- Frequency: 200Hz -20KHz
- Impedance: Subwoofer 3Ω, Speaker 4Ω
- Power output: Subwoofer (5W), Speaker (2W)
- Support: Micro SD (TF) card and USB flash disk
- Material: ABS
- Dimension (L x W x H): Subwoofer (135 x 135 x 135mm)  
Speaker (88 x 90 x 125mm)
- Weight: 886g

## Package Contents:

- Wireless speaker with subwoofer
- 3.5mm Auxiliary cable (1000mm)

## UNDERSTANDING THE PRODUCT



# START USING THE WIRELESS SPEAKER

## 1) Pairing the wireless speaker (switched off)

Step 1: Activate Bluetooth function on your mobile device to begin pairing with speaker.

Step 2: Switch on the speaker by switching the power adaptor connecting to the USB cable on.

Step 3: Connect to the speaker by selecting 'Valore BTS05' under the device list.

Step 4: Once connected, the speaker will notify.

Note: If the pairing is not successful, please turn off wireless speaker first, and then re-pair again. After pairing is successful, paired devices will remember each other. Unless pairing information is deleted because of new pairing, no need to pair when using the next time.

If you want to pair the wireless speaker with other devices, please turn off Bluetooth function of existing source device, and pair the wireless speaker with the new device according to steps 1-4 mentioned above.

## 2) Wireless speaker controls

**Mode:** Short press to switch between Bluetooth, Aux and Micro SD mode.

**Previous/Volume - :** Short press to go to previous song. Long press to reduce volume.

**Next/Volume + :** Short press to go to next song. Long press to increase volume.

**Play/Pause :** Short press to play or pause music. Long press to disconnect current Bluetooth.

# TROUBLESHOOTING

## **Issue 1: Speaker is unable to connect successfully to your mobile device**

Problem 1: Speaker's not on Bluetooth mode.

Solution: Short press the mode button to switch to Bluetooth mode.

Problem 2: Speaker not paired to your mobile device

Solution: Make sure that the speaker is successfully paired upon selecting 'Valore BTS05' in the device list.

Problem 3: Speaker and mobile device too far apart

Solution: Make sure that the speaker is within a metre range during pairing and connection.

Problem 4: Speaker is connected to other mobile device

Solution: Make sure that the speaker has already been disconnected before making a new connection with a new device.

## **Issue 2: Sound from the speaker is too soft or silent**

Problem 1: Speaker or mobile device's volume is too low

Solution: Turn the volume of the speaker or mobile device up to increase the volume.

Problem 2: Music track may not be audible

Solution: Make sure that the music track is of a playable format for the mobile device.

Problem 3: Speaker and mobile device might not be connected properly.

Solution: Repeat the connection step via Bluetooth again to make sure that it is connected properly and try again.

## TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at [v.info@valore.sg](mailto:v.info@valore.sg).
- For Warranty Registration, visit [www.valore.sg](http://www.valore.sg).

### Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the speaker in a high temperature environment.
- Do not place the speaker near a fire or other excessively hot environments.
- Do not expose this speaker to moisture or submerge it in liquid. Keep speaker dry at all times.
- Do not disassemble this speaker or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this headset. If there is any damage to the speaker such as dents, punctures, tears, deformities or corrosion, stop using the speaker and contact us immediately via email at [v.info@valore.sg](mailto:v.info@valore.sg), or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at [v.info@valore.sg](mailto:v.info@valore.sg).

### DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images (“Materials”) provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the (“Materials”) are the property of their respective owners and may be trademarks or registered trademarks.

Complies with  
IMDA Standards  
DA103331



Inspired by Valore Singapore

For full range of Valore products visit [www.valore.sg](http://www.valore.sg)