

Hummingbird - Wireless Earbuds (BTi34)

VALORE

Thank you for purchasing the Valore Hummingbird - Wireless Earbuds (BTi34).

Say goodbye to tangled wire frustrations! The Valore Hummingbird lets you wirelessly enjoy hours of rich, stereo music on the go. Connect your Hummingbird to two mobile phones simultaneously for convenience and efficiency.

Important: Please read the user manual thoroughly before using your wireless earbuds.


Specifications:

- Wireless range: Up to 10m
- Support: HSP/HFP/A2DP
- Battery type: Polymer Lithium-ion 50mAh
- Standby time: Up to 100 hours
- Charging time: Up to 2 hours
- Playback time: Up to 3 hours
- Power input: DC5V
- Dimension (L x W x H): 17 x 33 x 30mm
- Material: ABS + PC
- Weight: 6g

Package Contents:

- Wireless earbuds
- USB charging cable
- Pouch
- Ear tips x 1 pair

UNDERSTANDING THE PRODUCT




- ① Micro USB charging port
- ② Microphone
- ③ Multi-function button
- ④ LED indicator

START USING THE WIRELESS EARBUDS

1) Charging the wireless earbuds

Connect the USB charging cable provided to the Micro USB charging port located at the top of the earbuds. The red indicator is on when the earbuds are charging. When it is completed, the red indicator is off, and the blue indicator is on.



Note: Please charge the earbuds for at least 8 hours before first use. Please make sure that the earbuds are switched off when charging is in progress.

2) Pairing the wireless earbuds (switched off)

Step 1: Activate Bluetooth function on your mobile device to begin pairing with earbuds.

Step 2: Switch on both sides of the earbuds by long pressing the multi-function button till the LED indicator flashes purple. When one side is flashing blue and red and the other side is slow flashing blue, earbuds are ready to pair.

Step 3: Connect to the earbuds by selecting 'Valore BTi34' under the device list.

Step 4: Once connected, the LED light at the will be solid blue.

If the pairing is not successful, please turn off wireless earbuds first, and then re-pair again. After pairing is successful, paired devices will remember each other. Unless pairing information is deleted because of new pairing, no need to pair when using the next time.

If you want to pair the wireless earbuds with other devices, please turn off Bluetooth function of existing source device, and pair the wireless earbuds with the new device according to steps 1-4 mentioned above.

3) Wireless earbuds controls

Multi-function button (Right):

Pick up call - Short press

Hang up call - Short press

Reject call - Press and hold

Switch language - In pairing mode, double click to switch between chinese and english

Power on - Press and hold

Power off - Press and hold

Multi-function button (Left):

Switch between mobile and earbuds - Press and hold

To mute / unmute - Double click while in calling mode

Re-dial last number - In standby mode, double click

Play/Pause music - Short press

TROUBLESHOOTING

Issue 1: Earbuds is unable to switch on

Cause 1: Earbuds battery is flat

Solution: Fully charge the earbuds (2 hours) and retry connection with your mobile device.

Cause 2: Time of holding down multi-function button is too short.

Solution: Press and hold the multi-function button until the LED indicator is lit.

Issue 2: Unable to charge the earbuds

Cause 1: The charging cable is not properly connected.

Solution: Reconnect the charging cable to the charging port fully.

Issue 3: Unable to switch off earbuds


Cause 1: The earbuds program has an error due to an incorrect operation.

Solution: Charge and reset the earbuds.

Issue 4: The earbuds cannot be searched or paired.

Cause 1: The earbuds has not enter pairing state.

Solution: Press and hold the multi-function button until the LED indicator flashes blue and red, then the earbuds has entered pairing mode.



TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the earbuds in a high temperature environment.
- Do not place the earbuds near a fire or other excessively hot environments.
- Do not expose this speaker to moisture or submerge it in liquid. Keep earbuds dry at all times.
- Do not attempt to charge the earbuds using any other method or connection other than the headset's provided charging cable.
- Do not disassemble this earbuds or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this headset. If there is any damage to the earbuds such as dents, punctures, tears, deformities or corrosion, stop using the earbuds and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with
IMDA Standards
DA103331



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg