

# Quick Charge 10000mAh Power Bank (PB05-QC)

# VALORE

Thank you for purchasing the Valore Quick Charge 10000mAh Power Bank.

Pack enough juice to keep your devices charged up all day long. With the Qualcomm Quick Charge 2.0 technology packed in, you can now also enjoy quick-charge function for all fast-charging compatible devices. Anti-scratch coating keeps your power bank scratch-free for heavy duty use.

**Important:** Please read the user manual thoroughly before using your Power Bank.


## Specifications:

- Battery type: Built-in Polymer Lithium-ion
- Battery capacity: 10000mAh
- Input: 5V/2.0A (max)
- Output 1: 5V/2.5A (max)
- Quick Charge Output 2: 5V/2.4A, 9V/2A, 12V/1.5A (max)
- Charging time: 6 hours (5V/2.0A USB adapter)
- Recharging cycle: 500 times cycle
- Operating temperature: 0°C to 45°C
- Material: ABS + PC
- Dimensions (H x W x D): 155 x 78 x 12mm
- Weight: 252g

## Package Contents:

- 10000mAh Power Bank
- Quick Charge USB charging cable
- Soft pouch

## UNDERSTANDING THE PRODUCT




- ① LED indicator
- ② Power button
- ③ Micro USB charging port
- ④ USB output (DC5V/2.5A) (max)
- ⑤ Quick charge USB output (DC5V/2.4A, 9V/2A, 12V/1.5A) (max)

# START USING THE 7000MAH POWER BANK

## 1) Charging the power bank

Connect your power bank to the USB adapter (2.0A) using the charging cable provided. When the LED indicator displays 4 blue LED lights, it indicates that the battery is fully charged.



Power level:

One LED: <25%

Two LED: <50%

Three LED: <75%


Four LED: <=100%

*\*The above mentioned is for reference only*

Note: Fully charge the power bank for at least 14-16 hours before first use. This is to maximise the battery performance and prolonging the life of lithium ion batteries. Recharge your power bank once every three months when not in use or seldom used.

## 2) Charging of devices

Connect your power bank to your mobile device's micro usb port using the USB outputs. The quick charge USB output charge at 9V/2A, 12V/1.5A (max) for compatible devices and 5V/2.4A (max) for non compatible devices. Press the power button once to activate charging.



## TROUBLESHOOTING

### Issue 1:

Power bank is unable to charge your mobile device

**Problem 1:** Power bank battery is flat

**Solution:** Fully charge the power bank and resume charging your mobile device.

### Issue 2:

Power bank drains off quickly

**Problem:** Running multiple applications on your mobile device

**Solution:** Turn off all running applications on the mobile device and leave it to charge till full. Extra consumption of energy would be due to heat produced during the charging of your mobile device.

### Issue 3:


Unable to charge (power indicator is not flashing)

**Problem 1:** The voltage of the power adapter is too low.

**Solution:** Use 5V supply with at least 800mAh for charging.

**Problem 2:** Faulty cable

**Solution:** Check the cable to ensure that it is well connected or replace damaged cables.



## TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at [v.info@valore.sg](mailto:v.info@valore.sg).
- For Warranty Registration, visit [www.valore.sg](http://www.valore.sg).

### Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not dismantle or open the power bank
- Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy object on the power bank.
- Do not expose the power bank to water or other liquids
- Do not expose the power bank to heat and/or fire. Avoid storage in direct sunlight.
- Do not attempt to insert foreign objects into the power bank. Do not short-circuit the power bank by storing it haphazardly in receptacle where it may be short-circuited by other metallic or conductive objects.
- Do not use any charger\* other than that specifically provided for use with the power bank. Battery usage by children should be supervised.

\*The charger may also be known as the adaptor, and is used to charge the power bank

### DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images (“Materials”) provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes. The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered

trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the (“Materials”) are the property of their respective owners and may be trademarks or registered trademarks.



Inspired by Valore Singapore

For full range of Valore products visit [www.valore.sg](http://www.valore.sg)