

Valore Wireless Audio Receiver (SA01)

VALORE

Thank you for purchasing the Valore Wireless Audio Receiver (SA01).

The Valore wireless audio receiver allows your Bluetooth enabled mobile devices to connect with your wired earphones, headphone, speaker or car audio system for wireless audio streaming and hands-free calling. The simple controls let you play/pause your music and take/end calls easily anytime and anywhere you go.

Important: Please read the user manual thoroughly before using your wireless audio receiver.


Specifications:

- Wireless range: 10m
- Battery type: Built-in rechargeable
Li-polymer 80mAh
- Charging time: Up to 2 hours
- Playback time: Up to 5 hours
- Standby time: Up to 180 hours
- Power input: DC5V/500mA
- Material: ABS
- Dimension (L x W x D): 58 x 14 x 11mm
- Weight: 13g

Package Contents:

- Wireless audio receiver
- USB charging cable (200mm)
- Audio cable (500mm)

UNDERSTANDING THE PRODUCT



- ① Audio output
- ② Volume + / Next
- ③ Power button / Calling hands-free
- ④ Volume - / Previous
- ⑤ LED indicator
- ⑥ Microphone
- ⑦ Micro USB charging port

START USING WIRELESS AUDIO RECEIVER

1) Charging the wireless audio receiver

Connect your wireless audio receiver to the USB adaptor using the provided charging cable. The red LED light will switch on when charging.

2) Power On/Off

- a) To power on, press and hold the Power button for 3 seconds until LED flashes blue and red.
- b) To power off, press and hold the Power button for 3 seconds. LED will be switched off.
- c) If the device is inactive for 5 minutes, it will automatically power off.

3) Connecting audio device

- a) Connect a wired earphone by inserting the 3.5mm jack to the device's audio output port.
- b) Connect the speaker or car audio by inserting the 3.5mm jack connector and one end to the device and the other end to an audio player.

4) Pairing

Step 1: Activate Bluetooth function on your mobile device to begin pairing.

Step 2: Power on the device by long pressing the Power button till the LED indicator flashes blue and red.

Step 3: Connect to the device by selecting 'Valore SA01' under the device list.

Step 4: Once connected, the LED light at the will be solid blue.

If the pairing is not successful, please turn off wireless audio receiver first, and then re-pair again. After pairing is successful, paired devices will remember each other. Unless pairing information is deleted because of new pairing, no need to pair when using the next time.

If you want to pair the wireless audio receiver with other devices, please turn off Bluetooth function of existing source device, and pair the wireless audio receiver with the new device according to steps 1-4 mentioned above.

5) Controls

- a) Short press the Power button / Calling hands free to play/pause music and answer call.
Long press to reject calls.
- b) Short press Volume + / Next to increase volume. Long press for next song.
- c) Short press Volume - / Previous to decrease volume. Long press for previous song.

6) Language

- a) The default language is English. On standby mode, double press Power button / Calling hands free to change language.

TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the product in a high temperature environment.
- Do not place the product near a fire or other excessively hot environments.
- Do not expose the product to moisture or submerge it in liquid. Keep product dry at all times.
- Do not attempt to charge the product using any other method or connection other than the product's provided charging cable.
- Do not disassemble this product or attempt to repair or modify it in any manner.
- Battery usage by children should be supervised
- Be cautious of excessive drops, bumps, abrasions or other impacts to this product. If there is any damage to the product such as dents, punctures, tears, deformities or corrosion, stop using the product and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes. The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with
IMDA Standards
DA103331



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg