

8000mAh Wireless Charging Power Bank

VALORE

Thank you for purchasing the Valore Wireless Charging Power Bank.

Sleek and brilliantly thin, you can now travel light knowing you have a quick charge available anytime. Charge your Qi-compatible devices without the tangle of charging cables. In addition, charge up to two devices simultaneously via 2.1A output dual ports.

Important: Please read the user manual thoroughly before using your wireless power bank.


Specifications:

- Battery type: Polymer lithium-ion
- Battery capacity: 8000mAh
- Input: DC 5V/2.0A (max)
- Output 1: DC 5V/2.1A (max)
- Output 2: DC 5V/2.1A (max)
- Exchange rate: >80%
- Charging time: 8 hours
- Recharge cycle: 500 times
- Material: ABS
- Dimensions (L x W x H): 174 x 104 x 9mm
- Weight: 240g

Package Contents:

- Wireless charging power bank
- USB charging cable

UNDERSTANDING THE PRODUCT



- ① Output 1: DC 5V/2.1A (max)
- ② Micro USB input: 5V/2A (max)
- ③ Output 2: DC 5V/2.1A (max)
- ④ Wireless charging indicator
- ⑤ Multi-functional button
- ⑥ LED indicator

START USING THE WIRELESS POWER BANK

1) Charging the Power Bank (2.0A USB adapter to wall plug)

Connect your power bank to the USB adapter (2.0A) using the provided charging cable. One of the LED bulbs would flash continuously to indicate that it is charging in progress.

Note: Fully charge the power bank for at least 8 hours before first use. This is to maximise the battery performance and prolonging the life of lithium ion batteries. Recharge your power bank once every three months when not in use or seldom used.

2) After being fully charged

After the power bank is fully charged, the LED light will be turned off. Please disconnect the cable from the power bank.

Note: If a short circuit occurs, the power bank will turn off automatically and enter into safety-protection mode.

3) Multi-functional button

a) Power indicator display

Press the multi-functional button once to check the battery status of the power bank with LED indication.

4 LED (solid): 76% - 100%

3 LED (solid): 51% - 75%

2 LED (solid): 26% - 50%

1 LED (solid): 1% - 25%

1 LED (flash): Low battery (requires charging)

Note: The percentage displayed is only an estimate; some deviation is expected.

4) Charging the mobile device (1.0A ~ 2.1A)

Connect your power bank to your mobile device (1.0A ~ 2.1A) using the provided charging cable.

Note: The provided cable only charges your mobile devices with Micro USB functionality, not suitable for Apple products. Eg, iPod, iPhone and iPad.

5) Charging the Qi-Compatible mobile device

Simply place your Qi-Compatible device on top of the power bank, it will start charging automatically and the wireless charging indicator will lit.

Wireless charging device was given priority in charging followed by USB charging device.

TROUBLESHOOTING

Issue 1: Power bank is unable to charge your mobile device

Problem 1: Power bank battery is flat

Solution: Fully charge the power bank and resume charging your mobile device.

Problem 2: Incompatible cable (User's)


Solution: Use the original cable provided by either Valore or your mobile device.

Issue 2: Power bank drains off quickly

Problem: Running multiple applications on your mobile device

Solution: Turn off all running applications on the mobile device and leave it to charge till full.

Extra consumption of energy would be due to heat produced during the charging of your mobile device.



TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- The power bank will generate heat when charging. Always charge in a well-ventilated and open-air area. Do not charge under pillows, blankets, clothing or on flammable surfaces.
- Keep the power bank away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
- Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into the power bank.
- Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy objects on the power bank.
- Do not short-circuit the power bank or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.
- Do not operate the power bank if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury. Contact the dealer or authorized agent.
- Power bank usage by children should be supervised.

Please read the operating instructions (including charging instructions and information on the minimum and maximum operating temperatures), supplied with this power bank.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images (“Materials”) provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the (“Materials”) are the property of their respective owners and may be trademarks or registered trademarks.

Complies with
IDA standards
DA 103331



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg