

4K WiFi Action Camera (VMS51)

VALORE

Thank you for purchasing Valore 4K WiFi Action Camera.

With 4K image quality and 170° wide angle lens, the Valore Action Camera can capture your adventures in astonishing details, making them as breathtaking on screen as they are in real life.

Important: Please read the user manual thoroughly before using your 4K WiFi action camera.

Specifications:

- Image sensor: Sony IMX117
- LCD: 2.0" TFT screen
- Lens: 170°
- Resolution: 4K 3840 x 2160 @24fps /
2K 2560 x 1440 @30fps /
1920 x 1080 @60fps /
1920 x 1080 @30fps /
1280 x 720 @120fps /
1280 x 720 @60fps /
1280 x 720 @30fps /
WVGA P30 / VGA P240 /
VGA P30 / QVGA P30
- Still image resolution: 16M / 12M / 10M /
8M / 5M / 3M / VGA
- Input : 5V/1A
- Water resistance : Up to 30m
- WiFi distance: Up to 10m
- Battery type: 1050mAh lithium battery (included)
- Video format: MP4
- Video codec: H.264
- Photo format: JPG
- Dimension(L x W x H): 59 x 41 x 29mm
- Weight: 66g (with waterproof case 144g)

Package Contents:

- 4K WiFi Action Camera
- Waterproof casing
- Bicycle holder
- Mount x 4
- Switch support x 3
- Clip x 2
- Helmet base x 2
- Bandages x 4
- Lens cloth
- Wire rope x 4
- Protective backdoor
- USB cable
- Cable tie
- Adhesive x 2

UNDERSTANDING THE PRODUCT























- ① On/Off switch/Mode
- ② Indicator
- ③ OK
- ④ Mic
- ⑤ Micro SD card slot
- ⑥ Micro USB port
- ⑦ Micro HDMI port




- ① Charging indicator
- ② Operation indicator
- ③ Up/WiFi
- ④ Speaker
- ⑤ Down
- ⑥ Battery cover
- ⑦ Battery



Accessories

 Waterproof Housing	 Bicycle Holder	 Mount 1	 Mount 2	 Mount 3	 Switch Support 1	 Switch Support 2
 Switch Support 3	 Mount 4	 Clip 1	 Clip 2	 Helmet Base	 Bandages	 Battery
 Adhesives	 Cable Tie	 Wire Rope	 Protective Backdoor	 USB Cable		 Lens Cloth

Mounting



Mounting



1) Installing and removing battery

- a) Pull back the back cover lock to release the battery cap.
- b) Correctly install battery into action camera as indicated by +/- symbols and direction of arrowed marked on battery.

2) Charging

- a) While charging, a red indicator will be lit.
- b) When the battery is full charged, the red indicator will go off.

3) Switching On/Off

- a) Press and hold onto Mode/Power button for 3 - 5 seconds till welcome screen appears.

4) Mode switching

- a) After the action camera is switched on, short press the Mode/Power button to switch between video recording / photo shooting / playback & menu.
- b) Symbols of mode will be displayed on the top left of the screen.

5) Video recording & photo shooting

- a) Insert micro SD card, when in video recording mode, press OK button to start recording, the recording icon on the top left will start to flash. Press OK button again to stop recording.
- b) When in photo shooting mode, press OK button to take photos.

Note: Format your micro SD card before use.

Switch on the action camera, in setup mode, choose format and confirm action.

6) File storage & playing

- a) Micro SD card have to be Class 10 or above.
- b) Use a USB cable to export the videos into a computer, the action camera will prompt Mass Storage. Click on Mass Storage to play and store image.
- c) Use a card reader to access the image data on the micro SD card.

Note: Make sure the action camera is turned off properly before removing the micro SD card.

7) WiFi connection

- a) Install the application 'CANANY' on your mobile application store.
- b) Switch on the action camera. Short press the Up/WiFi button until the WiFi images comes up on the screen. A yellow LED will lit, which mean WiFi is switch on.
- c) Enable WiFi on your mobile and connect to 'Valore VMS51'. If password is required, key '12345678'.
- d) Launch the 'CANANY' application after your WiFi is connected for real-time display.

Note: For iPhone, download the app 'CANANY' from the App store. To download it on your iPad, go to the App store, search for 'CANANY', then select 'for iPhone' before downloading.

For Android, download th app 'CANANY' from the Google Play store.

TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the action camera in a high temperature environment.
- Do not place the action camera near a fire or other excessively hot environments.
- Do not expose this action camera to moisture or submerge it in liquid. Keep action camera dry at all times.
- Do not attempt to charge the action camera using any other method or connection other than the action camera's provided charging cable.
- Do not disassemble this action camera or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this action camera. If there is any damage to the action camera such as dents, punctures, tears, deformities or corrosion, stop using the action camera and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg