

Thank you for purchasing Valore 1080P Car DVR

Drive assured when you record every detail of your journey with 140° ultra wide-angle lens.

Important: Please read the user manual thoroughly before using your car DVR.

Specifications:

- Image sensor: 1.3 mega pixel CMOS sensor
- LCD: 1.5 inch TFT
- Lens: 140° ultra wide-angle
- Resolution: FHD 1920 x 1080 @25fps /
720p 1280 x 720 @30fps /
VGA 640 x 480 @60fps /
QVGA 320 x 240 @120fps
- Still image resolution: 12M/10M/8M/7M/5M/3M/2M/VGA
- Supports: G-sensor
Loop recording
Motion detection
- Input: 5V/2A
- Frequency: 50Hz/60Hz
- Battery type: 200mAh lithium battery
- Video format: AVI
- Storage expansion: Micro SD (TF) max 32GB (not included)
- Photo format: JPEG
- Dimension (L x W x H): 66 x 45 x 32mm
- Weight: 41g

Package Contents:

- 1080P Car DVR
- USB cable
- Mount
- Car charger

UNDERSTANDING THE PRODUCT



- ① Up
- ② Menu
- ③ Down
- ④ On/Off button
- ⑤ Mode/SOS
- ⑥ OK
- ⑦ Micro USB port
- ⑧ Mic
- ⑨ Reset
- ⑩ Micro SD card slot

START USING THE 1080P CAR DVR

1) Control buttons

a) Up button

Short press to zoom out when in standby and recording mode.

Up function in menu mode.

b) Menu button

Short press to show function settings.

c) Down button

Short press to zoom in when in standby and recording mode.

Down function in menu mode

d) Micro USB port

Connect external power to charge battery or connect to PC for data transfer.

When connected to a PC, the car DVR will show two modes available,

1) USB-DISK - in this mode you can access video and photo files.

2) PC-Camera - in this mode you can take photo or make video chat

e) OK button

In recording mode, press to start recording. Press again to stop.

In photo mode, press to take photo. Screen flashes to indicate photo is taken.

Confirmation button in menu mode.

f) Mode button

Short press to switch between photo mode, recording mode and playback mode.

g) On/Off button

Short press to switch on. Long press to switch off.

h) Reset slot

Use this to restart when crash.

2) Special features

a) G-sensor function

When gravitational acceleration reach 6g ($1g=9.80m/s$), car DVR will save present video as undeletable files.

b)SOS

Short press "M" to enforce saving the current video when video is recording.

3) Battery indicator



Full battery



Slightly low battery



low battery



battery empty

Trouble shooting:

Problem: Cannot take photo or record.

Solution: Check if Micro SD card has enough space or is locked.

Problem: Automatically stop when recording.

Solution: Use a compatible high speed Micro SD card. (Class 10 and above)

Problem: Appear “file error” when replaying video and photo.

Solution: Micro SD card storage error, please format your Micro SD card.

Problem: Unclear video


Solution: Check if there are any dirt or fingerprint and use lens clothe to clear the camera lens.

Problem: Black image when recording sky or water scenes.

Solution: Scenes with high contrast will influence the automatic exposure function of camera, you can adjust ‘EV’ in setting mode to correct exposure.

Problem: Cross stripe interference in image.

Solution: Reset ‘light frequency’ to 50Hz or 60Hz according to the local power supply frequency.



TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the car DVR in a high temperature environment.
- Do not place the car DVR near a fire or other excessively hot environments.
- Do not expose this car DVR to moisture or submerge it in liquid. Keep car DVR dry at all times.
- Do not attempt to charge the car DVR using any other method or connection other than the car DVR's provided charging cable.
- Do not disassemble this car DVR or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this car DVR. If there is any damage to the car DVR such as dents, punctures, tears, deformities or corrosion, stop using the car DVR and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg