

Thank you for purchasing Valore 1080P Car DVR (VMS63).

- Records high-quality 1080P video
- HDMI output allows playback on TV
- Seamless loop recording

\*Built-in battery is for emergency backup only, for normal use, please plug into power source.

**Important:** Please read the user manual thoroughly before using your car DVR.


### Specifications:

- Image sensor: 1/3" Progressive Scan CMOS
- LCD: 3 inch HD TFT
- Lens: 150° wide-angle
- Resolution: FHD 1080P (1920 x 1080P) @30fps / HD 720P (1280 x 720P) @30fps
- Still image resolution: 12M / 10M / 8M / 5M / 3M / 2MHD / 1.3M / VGA
- Input: 5V/1A
- Frequency: 50-60Hz
- Battery type: Built-in 3.7V 140mAh lithium battery
- Video format: MOV
- Storage expansion: Min 4GB, Max 64GB Class 10 microSD™ card
- Photo format: M-JPEG
- Dimensions (L x W x H): 86 x 36 x 47mm

### Package Contents:

- 1080P car DVR
- USB cable (800mm)
- Mount
- Car charger1080P car DVR
- USB cable (800mm)

## UNDERSTANDING THE PRODUCT





- |                   |                  |
|-------------------|------------------|
| 1. Lens           | 10. OK button    |
| 2. Speaker        | 11. Mode button  |
| 3. Indicators     | 12. Lock button  |
| 4. Display screen | 13. Power button |
| 5. Rear lens slot | 14. Down button  |
| 6. Bracket slot   | 15. Menu button  |
| 7. USB port       | 16. Up button    |
| 8. Reset button   | 17. TF card slot |
| 9. Microphone     |                  |

# START USING THE CAR DVR

## Insert Micro SD card

Put the Micro SD card into the slot, this camera can support max 64GB.

## Connect to power source

When charging the unit, the upper left side LED light will turn red. When fully charged, LED indicator will switch off.

## Power on/off

Power On: press the power button for 3 second, the camera will show start up screen and enters into Power on state;

Power Off: press the power button for 3 second when the camera is under idle mode to power off;

## Modes

To switch between modes, press the Mode button repeatedly until you access the mode of your choice. Once you've reached the mode of your choosing, you can press the Menu button to open the setting menu of that specific mode.

## Video Capture Mode

Use this mode to capture video with your dashcam. Under the video mode, press OK button to start video and press OK button again to end. When taking a video, short press lock button to lock the current video, then it won't be delete for circle recording.

## Photo Capture Mode

Use this mode to take photos with your dashcam. Press OK button to take photo.

## Playback Mode

Use this mode to view and manage photos and videos that you have already taken. When you are viewing the videos that you have already taken, press the up button to turn up the volume, or press the down button to turn down the volume.

## Accessing the Video Capture Mode Settings Menu

To make adjustments to how your dashcam records video you can access the video capture mode's settings menu. To do so, you must first make sure that you are in the video capture mode.

Next, press the Menu button once to access the video capture mode settings menu. Then press the Menu button again to access the general settings menu.

Once you are in the settings menu, you can press the Up and Down buttons to scroll through the various settings options. Press the OK button to confirm any settings options that you have selected, and press the menu button to exit.

## General Settings Menu

If your dashcam is powered on, and not recording video, then you can access the general settings menu from any mode. To do so, press the menu button twice to access the general settings menu. press up/down to select the submenu, then press the OK button to enter the submenu, press menu button to exit.

Setting	Description
Parking monitor	Open this function, When car shake strong, it will enter the parking monitor, and screen will show up a P icon.
date/ time setting	Press confirm button to enter the time setting.
Auto Power off	Press the confirm button to enter the menu, there is off/1minutes/3minutes/5minutes choose
Screen savers	Press confirm to enter the menu, press up/down to choose off/1 minute/ 3 minutes/ 5 minutes
Beep sound	Off/ on choice.
Language	Press the confirm button to enter the menu, press up/down to choose the language
Frequency	Press confirm to enter the menu, 50HZ/60HZ for optional.
License plate stamp	Press OK button to enter the license plate stamp setting.
Format	Press confirm to enter the menu, there are two choice cancel/ok (attention, if choose ok, it will format all the date of the card, including the protected file)
Default setting	Press OK button to enter the menu, there are two choice cancel/ok
Version	The software version will be showed up on the screen.

## TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at [v.info@valore.sg](mailto:v.info@valore.sg).
- For Warranty Registration, visit [www.valore.sg](http://www.valore.sg).

### Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the car DVR in a high temperature environment.
- Do not place the car DVR near a fire or other excessively hot environments.
- Do not expose this car DVR to moisture or submerge it in liquid. Keep car DVR dry at all times.
- Do not attempt to charge the car DVR using any other method or connection other than the car DVR's provided charging cable.
- Do not disassemble this car DVR or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this car DVR. If there is any damage to the car DVR such as dents, punctures, tears, deformities or corrosion, stop using the car DVR and contact us immediately via email at [v.info@valore.sg](mailto:v.info@valore.sg), or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at [v.info@valore.sg](mailto:v.info@valore.sg).

### DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Challenger Technologies Limited. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.



Inspired by Valore Singapore

For full range of Valore products visit [www.valore.sg](http://www.valore.sg)