

Valore Wireless Sports Headset (QKE7)

VALORE

Thank you for purchasing the Valore Wireless Sports Headset.

Enjoy the workout and music you love with snug-fit ear tips and crystal clear audio of Valore Sports Headset. Connect up to 10m away from a Bluetooth-enabled device.

Important: Please read the user manual thoroughly before using your wireless sports headset.


Specifications:

- Wireless range: Up to 10m
- Battery type: 75mAh (lithium polymer)
- Standby time: Up to 150 hours
- Charging time: Up to 2 hours
- Playback time: Up to 6 hours
- Cable length: 500mm
- Dimension (L x W x H): 35 x 30 x 30mm (Single earpiece)
- Material: ABS
- Weight: 14g

Package Contents:

- Wireless sports headset
- Micro USB charging cable (300mm)
- Size S, M and L ear tips

UNDERSTANDING THE PRODUCT



- ① Microphone
- ② Multi-functional button
- ③ Light indicator
- ④ Micro USB charging port
- ⑤ Volume '+' / Previous song
- ⑥ Volume '-' / Next song

START USING THE WIRELESS SPORTS HEADSET

1) Charging the wireless sports headset

Make sure the headset is fully charged in first use. The light indicator will flash, indicating the wireless sports headset needs to be recharged. Charge the headset with the micro USB cable provided which is compatible with any computer or cell phone charger. The charge indicator light will be red while charging, when fully charged, light indicator will turn blue.

Note: Please charge the wireless sports headset for at least 8 hours before first use. Please make sure that the headset is switched off when charging is in progress.

2) Pairing the wireless sports headset (switched off)

Step 1: Press Multi-functional button for 3 seconds to power.

When turned on, blue LED light will flash and a voice prompt will come after, then, your wireless sports headset is ready for use.

Step 2: Activate Bluetooth function on your mobile device to begin pairing with headset.

Step 3: Connect to the headset by selecting 'Valore QKE7' under the device list.

Step 4: Once connected, the wireless sports headset will beep.

Note: If the pairing is not successful, please turn off wireless sports headset first, and then re-pair again. After pairing is successful, paired devices will remember each other. Unless pairing information is deleted because of new pairing, no need to pair when using the next time.

If you want to pair the wireless sports headset with other devices, please turn off Bluetooth function of existing source device, and pair the wireless headset with the new device according to steps 1-4 mentioned above..

3) Re-pairing the wireless sports headset

Each time the wireless sports headset is turned on, it will attempt to connect to the last device it was paired with automatically (mobile device with Bluetooth function turned on).

The wireless sports headset will do as follows:

1. Connect to last connected devices automatically;
2. Be listed in the screen of devices as an output channel. Select 'Valore QKE7' as the output channel to play music.

Note: In some cases, the headset may need to be manually selected from your operating system sound or hardware output list.

4) Wireless sports headset controls

a) Volume

- Control the volume via the Bluetooth device itself.
- Control the volume by short pressing onto the Volume +/- buttons.

b) Play and Pause music

- Press Multi-functional button to pause the music
- Press again to resume playback

c) Next and Previous track

- Press and hold onto the Volume '+' button to go to next track
- Press and hold onto the Volume '-' button to go to previous track

5) Hands free calling

There will be a pause when there is a phone call.

Functions	Operation
Answer a call	Short press Multi-function Button
Reject a call	Long press Multi-function Button about 2 seconds until you hear a tone
End a call	Short press Multi-function Button
Redial the last number	Double click Multi-function Button
Call transfer (headset to phone)	Long Press Multi-function Button for 2 seconds
Call transfer (phone to headset)	Long press Multi-function Button for 2 seconds

TROUBLESHOOTING

Issue 1: Headset is unable to connect successfully to your mobile device

Problem 1: Headset's battery is flat

Solution: Fully charge the Headset and retry connection with your mobile device.

Problem 2: Headset not paired to your mobile device

Solution: Make sure that the headset is successfully paired upon selecting 'Valore QKE7' in the device list.

Problem 3: Headset and mobile device too far apart

Solution: Make sure that the headset is within a metre range during pairing and connection.

Problem 4: Headset is connected to other mobile device

Solution: Make sure that the headset has already been disconnected before making a new connection with a new device.

Issue 2: Sound from the headset is too soft or silent

Problem 1: Headset's battery is low / flat

Solution: Fully charge the headset and retry connection with your mobile device.

Problem 2: Headset or mobile device's volume is too low

Solution: Turn the volume of the headset or mobile device up to increase the volume.

Problem 3: Music track may not be audible

Solution: Make sure that the music track is of a playable format for the mobile device.

Problem 4: Headset and mobile device might not be connected properly.

Solution: Repeat the connection step via Bluetooth/ again to make sure that it is connected properly and try again.

TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the headset in a high temperature environment.
- Do not place the headset near a fire or other excessively hot environments.
- Do not expose this headset to moisture or submerge it in liquid. Keep headset dry at all times.
- Do not attempt to charge the headset using any other method or connection other than the headset's provided charging cable.
- Do not disassemble this headset or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this headset. If there is any damage to the headset such as dents, punctures, tears, deformities or corrosion, stop using the headset and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with
IDA standards
DA 103331



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg