

Bone Conduction Wireless Earphones (BTS31)

VALORE

Thank you for purchasing the Valore Bone Conduction Wireless Earphones (BTS31).

- Suitable for indoor/outdoor use
- Up to 6 hours playback time
- Open-ear design to stay alert to surrounding

Important: Please read the user manual thoroughly before using your wireless earphones.


Specifications:

- Wireless range: Up to 10M
- Built-in battery: 200mAh Lithium battery
- Standby time: Up to 240 hours
- Charging time: Approximately 2 hours
- Playback time: Up to 6 hours
- Power input: DC5V

Package Contents:

- Bone conduction wireless earphones
- Micro-USB charging cable (400mm)
- Noise-reducing earplugs x 1 pair

UNDERSTANDING THE PRODUCT




START USING THE WIRELESS EARPHONES

1) Charging the wireless earphones

Connect the USB charging cable to the earphones located on the side of the left side.

When charging, the LED indicator is red and the red light will go off when fully charged.



Note:

1. Recommended to charge earphones before first use.
2. Earphones cannot be use while charging.
3. If not in use for a long time, it is recommended to charge once a month to maintain battery life.
4. The earphones will automatically shut down if it is not connect to the device for more than 5 minutes.

2) Pairing the wireless earphones (switched off)

Step 1: Activate Bluetooth function on your mobile device to begin pairing with earphones.

Step 2: Press and hold onto the Power button (Right button) until the LED light flickers red and blue.

Step 3: Connect to the headphones by selecting 'Valore BTS31' under the device list.

Step 4: Once connected, the LED light at the Bluetooth button will blink blue in interval of 5 seconds.

Note: If the pairing is not successful, please turn off wireless headset first, and then re-pair again. After pairing is successful, paired devices will remember each other. Unless pairing information is deleted because of new pairing, no need to pair when using the next time.

If you want to pair the wireless headset with other devices, please turn off Bluetooth function of existing source device, and pair the wireless headset with the new device according to steps 1-4 mentioned above.

3) Wireless headset controls

a) Chinese to English switch

The power is not connect, and there is no pairing status. Press the left and right button together. When the prompt tone is heard, the switch is successful.

b) Play/Pause music

While in standby, click the left or right button to operate the player on phone.

c) Volume +

Double click the right button in music/call state to increase volume.

d) Volume -

Double click the left button in music/call state to decrease volume.

e) Previous track

In the music state, press the left button 3 times.

f) Next track

In the music state, press the right button 3 times.

g) Restore factory settings

Press and hold the left and right button for 3 seconds and press the red light for 3 consecutive times, indicating that the factory settings have been restored.

h) Low battery

The red light is always on and accompanied by a prompt tone.

4) LED indicator

Steady red: Charging

Red light off: Charging complete

Blue and red flash: Pairing mode

Slow blue fash: Connected/Playing music

Flashing blue: Received a call/call

TROUBLESHOOTING

Issue 1: headset is unable to connect successfully to your mobile device

Problem 1: Headset's battery is flat

Solution: Fully charge the headset (2.5 hours) and retry connection with your mobile device.

Problem 2: Headset not paired to your mobile device

Solution: Make sure that the headset is successfully paired upon selecting 'Valore BTS31' in the device list.

Problem 3: Headset and mobile device too far apart

Solution: Make sure that the headset is within a metre range during pairing and connection.

Problem 4: Headset is connected to other mobile device

Solution: Make sure that the headset has already been disconnected before making a new connection with a new device.

Issue 2: Sound from the headset is too soft or silent

Problem 1: Headset's battery is low / flat

Solution: Fully charge the headset (2.5 hours) and retry connection with your mobile device.

Problem 2: Headset or mobile device's volume is too low

Solution: Turn the volume of the headset or mobile device up to increase the volume.

Problem 3: Music track may not be audible

Solution: Make sure that the music track is of a playable format for the mobile device.

Problem 4: Headset and mobile device might not be connected properly.

Solution: Repeat the connection step via Bluetooth/auxiliary cable again to make sure that it is connected properly and try again.

TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the headset in a high temperature environment.
- Do not place the headset near a fire or other excessively hot environments.
- Do not expose this headset to moisture or submerge it in liquid. Keep headset dry at all times.
- Do not attempt to charge the headset using any other method or connection other than the headset's provided charging cable.
- Do not disassemble this headset or attempt to repair or modify it in any manner.
- Be cautious of excessive drops, bumps, abrasions or other impacts to this headset. If there is any damage to the headset such as dents, punctures, tears, deformities or corrosion, stop using the headset and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes.

The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with
IMDA Standards
DA102803



Inspired by Valore Singapore

For full range of Valore products visit www.valore.sg